



The Highland SS Cam Buckles are not only strong, they provide the added convenience of separating, for quick changeout of your cylinder. Flipping the cam buckle open allows the wire bail to separate from the clasp. There is no need to unthread the buckle. (fig.1)

Attach the wire bail to the clasp. Pull the webbing until snug. Close the buckle half way to hold the cylinder band taut (fig.4).



Thread the free end of the band through the final slot in the end of the buckle (fig.5)

Weaving the Buckle

After weaving the tank band through your BC, backpack or plate, pass the webbing through the wire bail and through the middle of the three slots. (fig. 2)



Pull the cam buckle closed so that it lies flat against the cylinder. Be sure that the enlarged protective webbing lies behind the buckle to protect the cylinder finish (fig.6)

Make a U-turn and pass the webbing through the slot closest to the wire bail (fig. 3).

