



Assembly Instructions for the Comfort Harness III

Step 1 select the strap with the Circular ring and upper section of the shoulder release



Step 2 Using a Plastic Triglode and D ring install on the webbing

Note: that the webbing is doubled up and the Triglode should be positioned as close to the stitching



Step 3 Slide the assembly through the lower section of the padding through the 1 inch webbing sewn into the pad



Step 4 Install a Triglode and D ring above the 1 inch sewn webbing



Step 5 Slide the Epaulet onto the webbing

Note the folded side should be closest to your neck this will reduce abrasion



Step 6 Slide the 2 inch webbing through the sewn 2 inch webbing on the padding



Step 7 Install the small epaulet through the padding loops and above the Epaulet



Step 8 Slide the short strap with the installed grommet on the top of the backplate, facing Down



Step 9 Install the Triglides to the Top of the Webbing on the Plate



Step 10 Insert the velcro tabs through the slots on the Backplate under the 2 inch webbing from the previous step fold the Velcro to lock it down



Step 11

Slide the webbing from the plate under the webbing off the shoulder straps.

REPEAT THIS PROCESS FOR THE SECOND SHOULDER STRAP



Step 12 Install the webbing from the shoulder straps through the Triglides installed on the webbing



Make your final decision after deciding the size required, Sizing is located on the back of the shoulder padding after installing the chest strap



Step 13 Install the waist belt webbing as shown



Step 14 Install the lower portion of the shoulder strap. The waist webbing goes through the attached Tri Glide.

Note the webbing angles forward



Step 15

The Upper and Lower sections attached as pictured

