

# Information about your Light Monkey canister light

Light Monkey has not yet provided a users guide with their LED canister light. Until factory documentation is available, Dive Gear Express offers the following guidelines:

**What's in the box:** Light head/lid assembly including goodman handle, canister/lid sealing O-ring, sealed battery & canister, charger & power cord, and this information sheet.

**How to Charge Battery:** Only charge the battery shortly before use. To charge remove canister lid from body exposing the canister/battery connection. Connect the battery to the charger – Red to Red and Black to Black. Plug charger into wall outlet . Charge battery until the status LED turns green, indicating the battery is fully charged.

**How to Prepare Light To Dive:** Charge battery the day before the dive. Inspect the light head lens and LED for any visible damage or loose particles. Inspect the O-ring for damage and contaminants. Place clean, unlubricated and undamaged O-ring on the lip of the lid. Position the banana plugs on canister lid to make contact with the battery connectors. Press canister lid onto the body and seal using the locking latches on both sides. Toggle the switch ON for no more than 30 seconds and then OFF to verify light is functioning.

## CAUTIONS

**DO NOT** expose the light to heat exceeding 100°F (37.7°C), such as in the trunk of a car, furnace rooms, engine rooms, etc. Prolonged exposure to heat will shorten the life of the batteries and possibly damage them.

**DO NOT** use any charger other than the supplied charger to recharge your light. Using incompatible battery and charger may cause combustion and injury, or cause permanent damage to the battery and/or charger.

**DO NOT** leave the charger attached to the battery for a prolonged period of time beyond the charging cycle as this could damage the battery and/or charger.

**DO NOT** store the light with the battery in a fully charged OR in a fully discharged state. Doing so may severely shorten the lifespan of the battery.

**DO NOT** store the light with the housing assembled. Allow the housing to vent by setting the lid in place but not closing the locking clamps onto the canister body.

**DO NOT** operate the light out of water for more than 30 seconds. If used out of water for more than 5 minutes the LED can build excessive heat and will automatically switch to a lower wattage setting. The LED can be reset by switching the light off, then back on.

**DO NOT** look directly into light when operating. UV light emitted by the LED could cause eye damage or burn.

**DO NOT** attempt to operate or store the light with the housing assembled if moisture has entered the housing or canister. If moisture has entered the light head or internal canister, return the light to Light Monkey for factory service

*Light Monkey Enterprises LLC*

*14075 S US Highway 441*

*Lake City, FL 32024*

*corey@lightmonkey.us*