

Applying Faceplate Protector to Predator

Step 1:

- Remove all dust, debris and smudges from faceplate using a lint-free cloth and compressed air.
- Spray faceplate with 5-1 water-alcohol solution, ensuring it is completely wet.

Step 2:

- With clean hands and wet fingers lightly grasp the faceplate protector by the top corners and place squarely on the wet faceplate.

Step 3:

- While pressing firmly on applicator, drag from the middle to the edges of the faceplate protector using a Left-Right-Up-Down-Top Left-Bottom Left-Top Right-Bottom Right fashion. Ensure that the faceplate protector does not move.

Step 4:

- Dive the Predator to securely seat the faceplate protector with high pressure.

Step 5:

- Inspect faceplate protector for any scratches, dust, bubbles, or any other debris and replace accordingly.

