

Packaging contains:



879642000385

- 1) 6-ft of 2-inch Harness webbing, with stainless-steel grommet
- 3) 1 Right waist-strap assembly (4.5-ft 2-inch webbing with one 2-inch D-ring and one 1-inch D-ring)
- 4) 1 Left waist-strap assembly (4.5-ft 2-inch webbing with two 2-inch D-rings, one 1-inch D-ring, and quick-release buckle)
- 5) 5 Stainless steel 2-inch belt slides
- 6) 2 Stainless steel 2-inch D-rings
- 7) 1 Stainless steel bent 2-inch D-ring
- 8) 1 Stainless steel 2 - i n c h waist strap release belt buckle
- 9) Left and right 1-inch chest strap Assembly



DIVE RITE[®]
EQUIPMENT FOR SERIOUS DIVERS

Deluxe Quick Release Harness
Item # BC1080Q

This harness utilizes nylon webbing for strength and comfort

The Dive Rite Deluxe Harness fits on all Dive Rite back-plates.

Great for technical diving with a backplate.

Swivel points on the shoulder-straps and a chest strap ensure a comfortable fit.



The quick-release buckle allows for easy don/doff of the harness.

**** Crotch Strap not included ****

www.DiveRite.com

©2021 Lamartek, Inc. dba Dive Rite
175 NW Washington St.
Lake City, FL 32055 USA

Threading Deluxe Harness with Quick-Release



- 1) Thread the 6-foot webbing piece through the upper shoulder strap slots, as shown in Figure A, positioning the webbing so the grommet is over the upper tank bolt-hole.
- 2) Using the right waist strap assembly (side without the quick-release buckle), weave the tail end through the two left (looking at the front of the back plate) waist slots - starting from the front, then through the inner slot, and back out through the outer slot.
- 3) Repeat step 3 with the left waist-strap assembly (side with the quick-release buckle).
- 4) Using Figure B, install one 2-inch belt slide and one 2" D-ring on each tail of waist straps.
- 5) Using Figure B, install one 2-inch belt slide on each shoulder strap.
- 6) Install one 2-inch belt slide with one 2-inch bent "D"-ring on right shoulder strap.
- 7) Weave the tail of the right shoulder-strap through the D-ring located on the waist-strap as shown. Then weave the webbing back through both 2-inch belt slides.
- 8) Weave the tail of the left shoulder-strap through the slot in the quick-release buckle on the left waist-strap. Then weave the webbing back through the 2-inch belt-slide.
- 9) Using the right chest-strap assembly (with buckle), loop the webbing through right-side pivot D-ring and weave back through the plastic belt slide.
- 10) Using the left chest-strap assembly, loop webbing through the left-side pivot D-ring and pull tail through ring.
- 11) Weave tail of left chest-strap assembly through the slots in the quick-release buckle of the right-side chest-strap assembly.
- 12) Install the optional crotch strap components (not included) as shown in Fig. "D".
- 13) Install the waist-strap release buckle on the same side of the waist-strap as the crotch-strap loop is installed.